



by **TOYOTA**

## GLOBAL VOICE COMMANDS

Global voice commands can be spoken anywhere in the system. Use them to move easily between the communication, entertainment and navigation functions.

- Help
- Cancel
- Go Back or Previous
- Next or Skip
- Tutorial
- Scroll Down or Page Down
- Scroll Up or Page Up
- Select <line number> (example: "Select Four" or "Select Line Four")
- Notifications
  
- Go to Entertainment
- Go to Navigation
- Go to Communication
- Go to Settings
- Go to Home (Screen) or Go to Main Menu
- Turn Display Off or Turn Screen Off
- Display Clock
  
- Go to Messages | Notifications or Show Messages
- Go to Contacts | Phonebook or Show Contacts | Phonebook
- Go to Phone or Dial Phone
- Go to | Show (Call) History or Go to | Show Recent Calls
- Go to Text or Go to SMS
- Go to Aha (Radio) or Play Aha (Radio)
- Go to AM (Radio) or Play AM (Radio)
- Go to Line In | Auxiliary | Aux or Play Line In | Auxiliary | Aux
- Go to Bluetooth (Audio) or Play Bluetooth (Audio)
- Go to FM (Radio) or Play FM (Radio)
- Go to Pandora or Play Pandora
- Go to Stitcher or Play Stitcher
- Go to USB (Audio) or Play USB (Audio)
- Go to USB 1 or Play USB 1
- Go to USB 2 or Play USB 2
  
- Call or Dial
- Call | Dial (by) Number
- Call | Dial (by) Name
- Call | Dial <number> (example: "Call 555-1234")
- Call <contact name> <contact type>
- Call Back
- Redial
- Dial Pad
- Play or Resume
- Pause or Stop
- Play Song
- Play Playlist
- Play Artist
- Play Album
- Play Genre
- Play Audiobooks
- Play Podcasts
- Play Folder
- Play Playlist <playlist name>
- Play Artist <artist name>
- Play Album <album name>
- Play Genre <genre name>
- Play Folder <folderName>
- Play <artist name>
- Play <album name>
- Play <genre name>
- Tune to | Station <frequency AM or frequency FM>
- Tune to <channel number
- Browse Playlist <playlist name>
- Browse Artist <artist name>
- Browse Album <album name>
- Browse Genre <genre name>
- Browse Folder <folderName>
- Browse
- Browse Song
- Browse Playlist
- Browse Artist
- Browse Album
- Browse Genre
- Browse Folder
  
- Navigate to <address> or Enter | Drive to <new address>
- Clear Route or Cancel Route